



Logosol USB to LDCN NODE Isolated Adapter LS-832

Doc. # 711830007 / Rev. 1.0, 11-Jan-2012

DIMENSIONAL DRAWING



PINOUT



INTERFACING

- The USB cable length between LS-832 and the host should not exceed 16 ft. or 5m.
- The cable length between LS-832 and the first LDCN node should not exceed 100 ft or 30m.
- For software drivers and installation refer to FT232BM on FTDI Web page:

<http://www.ftdichip.com/FTProducts.htm>

ORDERING GUIDE

| PART NUMBER | MODEL | DESCRIPTION |
|-------------|--------------|---|
| 921830008 | LS-832-S | USB to LDCN NODE Isolated Adapter - side entry |
| 921830009 | LS-832-S-C06 | USB to LDCN NODE Isolated Adapter - side entry With 6ft LDCN cable |
| 921830010 | LS-832-T | USB to LDCN NODE Isolated Adapter – top entry |
| 921830011 | LS-832-T-C06 | USB to LDCN NODE Isolated Adapter – top entry With 6ft LDCN cable |